

DEMOUNTING



4a. Remove the plastic covers from the brackets.

4b. Push with your thumb against the lever on the bearing until the slot opens.

You can also use a screwdriver. You should then however take care to hold the blind in place, while pressing, in order to avoid dropping the blind after it's release from the brackets.

“SOFT-RAISE” SPRING OPERATION

When installing a Luxaflex® roller blind with “Soft-raise” spring, it is sometimes useful to adjust the tension of the spring. This is done as follows:

Always first install the roller blind, as described above.

To increase the tension:

Pull the blind down and lock it into position. Demount the blind from the brackets and roll it up again by hand.

NB: every turn helps to increase the tension on the spring. Re-insert the blind into the brackets and test the tension again by pulling the blind down and letting it roll up.

To decrease the tension:

Let the blind roll up completely, but make sure it is locked in position. Demount the blind from the brackets and roll the fabric off by hand. With every turn the tension on the spring will decrease. Re-install the roller blind into the brackets and test the tension by operating the blind.

Installation and operating instructions Roller Blinds

SUNWAY®

SUNWAY®

The Sunway Roller Blind Collection comes with the following components:

- 1 set of steel mounting brackets with plastic covers

STANDARD INSTALLATION

Make sure that the position of the brackets is such that the Sunway roller blind will not come into contact with protruding parts, such as window or door handles, window sills etc.



1a. Installation of standard brackets

The brackets can be used for: wall mounting (1a), ceiling mounting (also suitable for inclined ceilings) (1b) or fixing to the side, in the recess of the window (1c). The same bracket is used at both ends of the roller.

1b. Positioning of the brackets

Mark the position of the holes for the first bracket, drill the holes and fix the bracket in place. It is recommended to insert the bracket cover over the bracket before marking the position of the bracket. Then place the other bracket on the other end of the blind and mark its position. (The blind should have 2mm of play between the brackets and roller.) Make sure that the second bracket is marked so that it is level with the first, drill the holes and fix the bracket in place.

Installing the roller blind

NB: It is easier to install the blind into the brackets while the plastic bracket covers are removed.

2. Chain/Endless cord

2a. Insert the control side of the blind in the bracket. The control side has a star-shaped hole, which makes it possible to mount the blind in different angles. Make sure that the chain/endless cord hangs straight downward.

2b. Bring the bearing end of the blind to the lip of the bracket. Align the slot on the bearing with edge of the bracket. Gently push the bearing into the bracket until a 'click' is heard. This can be done either from the top or under side.

2c. Insert the plastic covers over the mounting brackets.

3. "Soft-raise" spring operation

3a. Insert the cross-shaped opening of the spring, on the LH side of the blind in the bracket. If you have ordered your blind to be "reverse rolled" (cloth rolling to room side), the cross shaped opening should be mounted to the RH bracket. (The positioning of the cross onto the brackets is not important).

3b. Bring the bearing end of the blind to the lip of the bracket. Align the slot on the bearing with edge of the bracket. Gently push the bearing into the bracket until a 'click' is heard. This can be done either from the top or under side.

