

FITTING GUIDE: 2.1 ASSEMBLING OTHER DESIGNS

Design: Top Opening



Assembling the Deco frame for top opening windows is no different, just follow the standard guide.

Design: Half Height



3 sided bottom frames are supplied with a flat top, 3 sided top frames are supplied with a flat bottom.
Once assembled handle 3 sided Deco frames with care when lifting.

Design: Tposts



Tposts are treated like part of the frame. Assemble the main outer frame first, then fit the Tposts, they are labelled at the end and come with pre-drilled holes.

Lay the frame face up on the floor. Place the Tposts into position and screw through the top and bottom frames to secure into place.

Check the shutters and Tposts are correctly spaced by fitting the panels in the frame, make any adjustments then remove the panels so you are ready to fit the frame.

Design: Shaped Deco frames



Assembling shaped Deco frames will vary per design. Some smaller shapes will come completely pre-made, others will need to be made.

All the joints will come pre-cut and either use the interlocking key design or need to be screwed.

Lay the frame face down on the floor and follow the same guide as sheet 1.

Note, curved Deco frames orders will not have any removable inserts.