

FITTING GUIDE: 2.5 FITTING TPOSTS

Design: Tposts



Tposts are an extra part of the frame that need to be screwed into place before you fit the shutters. On a Deco frame they will add strength to the frame and make it easier to lift into place and level up.

Once the main outer frame is assembled, the Tposts are screwed in through the top and bottom frames (or sill plate). The Tposts are labelled and the fixing holes are pre-drilled.

With the front of the frame facing you and the top furthest away, place the Tposts into position within the frame.

Screw the Tposts into place using one of the small 40mm screws provided. Use one screw first then check the shutters and Tposts are evenly spaced by fitting the shutters into the frame temporarily.

Fit the panel feet to the bottom of the shutters, fit the shutters in the frame and connect them together using the hinge pins to achieve the correct spacing.

If any adjustments are required, loosen the single screw in the Tpost and make your adjustments, use the second screw to secure the Tpost into place, then re-tighten the first screw.

There are no removable inserts on the Deco frame Tposts so the main fitting will be the same as a 4 sided frame.

Design: Tposts



Hinge screws - When the fitting is complete one of the last jobs is to screw in the final locking hinge screws. Tposts come with smaller hinge screws, these are designed for the Tpost hinges rather than the main frame hinges.

Screw them into place when you happy with the final fitting.