

FITTING GUIDE: 6.1 ASSEMBLING OTHER DESIGNS

Design: Top Opening



Assembling the shutter frame for top opening windows is no different, there are just more hinges mounted on the side frames. Make sure you mark the top of the frame so you know which is top.

Design: Half Height



4 Sided - Assembling 4 sided half height frames will be the same as the main guide.

3 Sided (Top) - When there is no bottom frame, the sides are supplied with mitred tops and flat bottoms.

3 Sided (Bottom) - When there is no top frame, the sides are supplied with mitred bottoms and flat tops.

Assemble 3 sided frames in the same way as a 4 sided frame, there will just be one less frame to put together.

Once the 3 sided frames are assembled handle them with care when lifting. The interlocking keys keeping the mitres together are not designed to take any weight.

Design: Examples



Examples of pre-assembled frames that are ready for fitting